


7. Water & Air diagrams

Figure 36 Water & Air diagram (delivery head)











-  1. 1/8" orange, the total switch back air path
-  2. 1/8" black, the total switch supply air path
-  3. 1/8" blue, water tube
-  4. 1/8" yellow, main air supply tube
-  5. 1/4" black, pedal drive air
-  6. 1/8" red, state valve
-  7. 1/8" white, reserved
-  8. 1/8" brown, reserved

Figure 37 Classic100 Water & Air diagram (water unit)




Figure 38 Classic101 Water & Air diagram (water unit)

